

# Installation Manual: clickahoy Standard

A GUIDE TO SMART BOATING

V2.1

## Interface

---


Supply Voltage Monitoring  
Analog Inputs 2  
Digital Inputs 1  
Bluetooth Temperature Sensor 4  
Digital Output 2

## Included

---

Advanced LTE Modul  
Internal Battery  
International Simcard  
IP65 Waterproof Case







Connection to the c.technology Cloud





# 1. Pinout

The following table shows an overview about the interfaces of the clickahoy Standard. **The colors in the most left column correspond to the color of the signal cables from the clickahoy system**

clickahoy Standart	Pin Name	Description	Sensor & Components
 +10...30 V DC	VCC (10-30V) DC (+)	Power Supply (10-30 V DC)	Main Battery (+)
 GND	GND (0V) (-)	Ground Pin DC (-)	Main Battery (-)
 DIN2-N/AIN1	AIN1	Analog Input 1. Input Range: 0-30V	Fuel Sensor / Battery / Landline / Wassersensor
 DIN3/AIN2	AIN2	Analog Input 2. Input Range: 0-30V	Arbitrary Analog Sensors / Landline / Wassersensor
 DIN1	DIN1	Digital Input 1, Input Range 0-30V, Threshold 7.5V, 47k Pull Down	Landline / Wassersensor / Arbitrary Digital Sensor
 DOUT1	DOUT 1	Digital output 1. Open collector output. Max. 0,5 A DC.	Contact Us!
 DOUT2	DOUT 2	Digital output 2. Open collector output. Max. 0,5 A DC.	Contact Us!
 DOUT3	DOUT 3	Digital output 3. Open collector output. Max. 0,5 A DC.	Contact Us!

**Note:** VCC and GND need to be connected directly to the main(starter) battery such that the system is powered by permanent supply. This ensures full security and 24/7 connectivity.

### Power Characteristics

Input Voltage Range	VCC (10-30V) DC (+)
Internal Battery	GND (0V) (-)
Power Consumption	<5 mA (sleep) <30mA (nominal)



**Attention!** Watch out for possible electric shocks. Never touch both poles of a battery at the same time.



## 2. Sensors and Components

The clickahoy system offers the ability to observe and control various analog and digital sensors, through connecting with the corresponding inputs. Keep note which sensor is connected to which input, since it will be configured in the clickahoy App or clickahoy WebApp later.




### Main Battery - Required

Connect to: VCC, GND - Required


Connect Battery (+) with VCC and Battery (-) with GND. The clickahoy system needs permanent power supply to ensure full security and 24/7 connectivity.

**Optional:** Insert a 1A fuse between Battery (+) and VCC.



### Additional Battery

Connect to: AIN1 or AIN 2 - Optional



Connect addition battery (+) to an analog input. Battery (-) is **not** connected. The potential is measured against Main Battery (-), which should be on the same potential as additional Battery (-) due to internal connection.



### Fuel Sensor

Connect to: AIN1 or AIN 2 - Optional

Connect the signal from the fuel gauge or fuel sensor to an analog input. By default, the color of the fuel signal cable is purple. If no clear signal cable can be identified, look for markings or diagrams on the tank sensor that may help.


Additionally, the voltage of the signal can be measured. To do this, the tank sensor must be connected, and the ignition switched on. The voltage of the tank signal is in the range ~1V.-8V.



## Landline Detection

Connect to: AIN1 or AIN 2 or DIN1 - Optional

Connect the GND signal from the 3 pol socket of the landline detector module to either an analog or digital input. Connect VCC of the 3 pol socket to permanent supply voltage (12V or 24V). Refer to the landline manual for more information!



## Water Sensor

Connect to: AIN1 or AIN 2 or DIN1 - Optional


Connect the signal from the water sensor an analog or digital input.



## Arbitrary Digital Sensor

Connect to: AIN1 or AIN 2 or DIN1 - Optional

Any additional, digital sensor can be observed. The requirement is that the sensor has an observable, digital signal which determines the state of the sensor. The digital inputs have an internal pull down.



Various sensors can be ordered directly via ctechnology. Contact us for more information.

### 3. Function Check

A function check can be done via [app.clickahoy.io](http://app.clickahoy.io). Therefore, enter the 6-digit code provided for that boat.

**Note I:** An account (mail & password) must be created in advance

**Note II:** The 6-digit code must be provided to the owner of the vehicle!



### 4. App

1. Download the clickahoy app from the App Store or Play Store and open it.



2. Sign in with your account (or create a new one if you don't have one).
3. If the app is launched for the first time, follow the steps in the installation wizard. It can take up to 30 minutes until your boat is connected for the first time.
4. Once the boat is connected, you can use the app normally.
5. To make settings go to *Menu* (top left) -> *Settings* and then to *Boots Settings* to configure your sensors.

Congratulations! Now you have a fully digitized vehicle and benefit from more safety, control, and comfort. Manufactured and developed with cutting-edge technology from Switzerland!

